How to install Your Little Free Library

Materials

- 8 ft 4" x 4" post
- 2 ft 2" x 6" piece of wood
- 6 2 1/2" lag screws
- 3" exterior lag screws
- **1.** To start, you will need an **8 ft. 4" x 4"** treated post. Any kind will work, but cedar tone is our favorite.
- 2. Cut the post 5 ft. long.
- **3.** With the remaining piece make side angle braces. Cut each piece **10** 3/4" long and cut **45°** angles on the ends.
- **4.** Cut a platform as wide as the Little Free Library out of the **2"** x **6"** piece of wood.
- **5.** Mount the angled braces to the **5 ft.** post with **3" exterior lag screws** and then attach the **2"x 6"** platform using **6-2 ½"** lag screws. First, pre-drill a slightly smaller hole to make it easier to install the lag screw. Use **3" lag screws** to enhance the holding power.
- **6.** Dig a **24"** deep hole and install the post. Make sure to use a level and tamp the dirt hard with a shovel to secure the post.
- 7. Drill 6 holes through the bottom of the Little Free Library. The holes need to match up with the post platform. Use the 6-2 1/2" lag screws to attach the platform to the library.
- **8.** You are done! Now take a picture of you and your friends by your Little Free Library and register it via our website: www. littlefreelibrary.org. Go to the contacts section to find registration.
- **9.** Build another Little Free Library. People always say, you can't just build one!







